







## Mast & Floodlights spare parts



Floodlight head



Floodlight support



Anti-drag spacer



Multiposition handle



Mast winch



Junction box



Coiled cable



**Bubble level** 



Mast rotation lock pin



Mast winch handle



Mast rope L.4300 mm full eyelet / free cable



Mast rope L.1460 mm full / dug eyelet



Mast rope L.1455 mm full / dug eyelet



Mast rope L.1415 mm full / dug eyelet



Angular runner



Angular runner reinforcement



Pulley D.60



Pulley D.62



Pulley D.63









# Electrical spare parts



Battery charger gauge



Selector



Inlet plug 230V 16A



Timer



Lamp switch



Green signal lamp



**Battery** 



Battery charger



Battery connector



8 modules cover



Earth post



Junction box



Emergency stop button



Battery charger socket









**4** + 39 02 942 1724

info@trime.it

www.trime.it

### Chassis spare parts



Handle with lock



Door hinge



Door retention rope



Stabilizer lock pin



Left stabilizer beam



Right stabilizer beam



Front stabilizer



Mudguards Rubber buffer



Jockey wheel



Coiled cable & electrical connector for towing



Stabilizer crank handle



Pin lock with spring



Handle



Plastic cover



Stabilizer rubber buffer



Right mudguard



Left mudguard



|4|

Wheel



White reflector



Orange reflector













# Chassis spare parts



Multi-function rear right light



Multi-function rear left light



Multi-function rear right light



Multi-function rear left light



Multi-function rear light



Trailer socket kit



Lighting Tower Specialist

TRIME s.p.a.

Strada per Robecco, snc

20081 Cassinetta di Lugagnano (MI) - ITALY

Tel. +39 02 942 1724

www.trime.it - info@trime.it